



First-time Use



初めての使用



clear

ARC Air 2

Open Ear AI Headphones

User Manual

Cleer ARC Air 2 Earbuds Model: GS1518E


Fitting

Slide the earhook behind your ear.



取り付け

イヤーフックを耳の後ろに滑り込ませてください。



Tips

- How to set up your iPhone to answer calls with Bluetooth earbuds: [Settings] → [Accessibility] → [Touch] → [Call Audio Routing] → [Bluetooth Headset]
- Volume sync setting
 - The volume levels between iPhones and earbuds are automatically synchronized.
 - Volume levels between some Android phones and earbuds are out of sync. For specific setup instructions, please contact the phone manufacturer's support.

Quick Troubleshooting

- Low volume issue: Typically caused by unsynchronized volume levels between the earbuds and phone. Please refer to the "Volume sync setting" method above.
- Earbuds don't charge in the charging case: First make sure the charging case is charged. Then check the charging contacts of the earbuds and the charging case respectively, and use soft cloth to clean up the dirt on the contacts and then try again.
- Earbuds are not when charging: When charging earbuds in charging case, especially the earbuds with 0% battery level, it is normal to be slightly hot for the earbuds during fast charging. After taking the earbuds out of the charging case, the temperature of earbuds will return to normal. But when the earbuds become extremely hot, take them out of the charging case immediately and contact the after-sales service for further processing.

Maintenance

- If the earbuds are exposed to dust, sweat, ink, oil, pollen, or chemicals (such as soap, hand sanitizer, shampoo, shower gel, laundry detergent, detergent, cosmetics, anti-UV products, antibacterial spray, high-concentration alcohol, insecticide, and mosquito incense) and other substances that may cause damage to the earbuds, please dampen a piece of cloth slightly with water and wipe the earbuds. Then, wipe them with a piece of dry, soft lint-free cloth and dry them in the air.
- Do not use any chemicals or organic solvents (such as soapy water, hand sanitizer or other acid-base solvents) to clean the earbuds, or the residual may cause skin irritation.
- Please regularly use a soft, lint-free cloth to wipe the earbuds. Do not use paper towels or cloth containing wood fibers. Do not use dirty or abrasive cloth.
- When you put the earbuds back into the charging case for charging, please make sure that the earbuds are dry and clean.
- Use and store the product and its accessories within the temperature range of 5°C to 35°C. Operating the device in temperatures that are too high or too low may cause malfunctions. When the temperature drops below 5°C, battery performance may deteriorate.

Skin Irritation Notice

- A small number of users may experience skin reactions due to certain materials, specially when exposed to specific environments or prolonged contact with potential irritants such as soap, sweat, sunscreen, or lotion.
- To minimize the risk of skin irritation, avoid wearing the product on areas of broken or injured skin.
- Keeping your earbuds clean and dry can help reduce the chance of irritation.
- Remember to take off your earbuds regularly to let your skin breathe and your ears relax.
- If you have sensitive skin, it is recommended not wearing the earbuds for more than 3 hours at a time.
- If you notice redness, swelling, itching, or any other signs of skin irritation, stop using the product immediately and consult a doctor.

Warranty

Cleer Limited Warranty

Cleer Limited warrants this product against defects in material or workmanship for (1) year as set forth below when purchased directly from Cleer Limited or a Cleer Limited authorized retailer. Pursuant to this Limited Warranty, Cleer Limited will, at its option, (i) repair the product using new or refurbished parts or (ii) replace the product with a new or refurbished product. For purposes of this Limited Warranty, "refurbished" means a product or part that has been returned to its original specifications. In the event of a defect, these are your exclusive remedies.

Labor: For a period of (1) year from the original date of purchase of the product ("Labor Warranty"), Cleer Limited will, at its option, repair or replace with new or refurbished product, product determined to be defective. If Cleer Limited elects to replace the product under this Labor Warranty has expired but while the parts warranty is still in effect, it will do so for the applicable labor charge.

Parts: For a period of (1) year from the original date of purchase of the product ("Parts Warranty"), Cleer Limited will supply new or refurbished replacement parts in exchange for parts determined to be defective.

This Limited Warranty covers only the hardware components packaged with the Product. It does not cover technical assistance or software use and it does not cover any software products whether or not contained in the Product; any such software is provided "AS IS" unless expressly provided for in any enclosed software Limited Warranty. Please refer to the End User License Agreements included with the Product for your rights and obligations with respect to the software.

Instructions: To obtain warranty service, you must deliver the Product, freight prepaid, in either its original packaging or packaging affording an equal degree of protection to the original Cleer Limited retailer (point of purchase) or Cleer Limited Customer Service. It is your responsibility to backup any data, software or other materials you may have stored or reformatted during service and Cleer Limited will not be responsible for any such damage or loss. A dated purchase receipt from Cleer Limited or a Cleer Limited retailer is required. For specific instructions on how to obtain warranty service for your product, visit the Cleer Limited website: www.cleeraudio.com

Following warranty service your original Product or a replacement Product will be returned to you as your Product was configured when originally purchased. Repair/Replacement Warranty: This Limited Warranty shall apply to any repair, replacement part or replacement product for the remainder of the original Limited Warranty period or for (90) days, whichever is longer. Any parts or product replaced under this Limited Warranty will become property of Cleer Limited.

This Limited Warranty shall not apply to: (a) consumable parts, such as batteries that are designed to diminish over time, unless failure has occurred due to a defect in materials or workmanship; (b) cosmetic damage, including but not limited to scratches, dents and broken plastic on parts; (c) defects caused by normal use or otherwise due to the normal age of the device; (d) damage caused by accident, negligence, abuse, misuse, fire, earthquakes, acts of God or damage resulting from liquid outside of the approved levels; (e) damage caused by operating the device outside Cleer Limited published guidelines; (f) damage caused by service performed by anyone who is not a representative of Cleer Limited or a Cleer Limited authorized service provider; (g) Products whose seals are tampered; (h) Products whose serial numbers have been removed or defaced from such Product; (i) modifications, alterations or repairs to the Product made by a party other than Cleer Limited or a party authorized by Cleer Limited; (j) any failure by End User or a third party to comply with environmental and storage requirements for the Product specified by Cleer Limited, including, without limitation, temperature or humidity ranges; or (k) use of the Product in combination with any third-party devices or products that have not been provided or recommended by Cleer Limited.

LIMITATION ON DAMAGES: CLEER LIMITED SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT.

DURATION OF IMPLIED WARRANTIES: EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED TO THE DURATION OF THIS WARRANTY.

DISCLAIMER: THE LIMITED WARRANTY SET FORTH HEREIN IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES OR CONDITIONS RELATING TO THE PRODUCT, WHETHER EXPRESS OR IMPLIED, AND CLEER LIMITED EXPRESSLY DISCLAIMS ALL OTHER WARRANTIES AND CONDITIONS WHETHER EXPRESS, IMPLIED OR STATUTORY, INCLUDING ANY IMPLIED WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT, FITNESS FOR A PARTICULAR PURPOSE, AND ANY WARRANTIES ARISING OUT OF COURSE OF DEALING OR USAGE OF TRADE AND AGAINST HIDDEN DEFECTS, TO THE FULLEST EXTENT PERMITTED BY LAW. CLEER LIMITED DOES NOT WARRANT THAT THE PRODUCT WILL MEET CUSTOMER'S REQUIREMENTS OR THAT USE OF THE PRODUCT WILL BE UNINTERRUPTED OR ERROR FREE. NO ADVICE OR INFORMATION, WHETHER ORAL OR WRITTEN, OBTAINED FROM CLEER LIMITED OR ELSEWHERE WILL CREATE ANY WARRANTY NOT EXPRESSLY STATED IN THIS WARRANTY.

Notice

Recycling

Your product is designed and manufactured with high quality materials and components, which can be recycled and reused. When you see the crossed out wheel bin symbol attached to a product, it means the product is covered by the European Directive 2002/96/EC.

Never dispose of your product with other household waste. Please inform yourself about the local rules on the separate collection of electrical and electronic products. The correct disposal of your old product helps prevent potentially negative consequences on the environment and human health. Your product contains batteries covered by the European Directive 2006/66/EC, which cannot be disposed of with normal household waste.

The device complies with RF specifications when the device used at 0mm from your body. Hereby, Cleer Limited, Declares that the product compliance with essential requirements and other relevant provisions of Directive 2014/53/EU.

The device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:
(1) This device may not cause interference.
(2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:
1) l'appareil ne doit pas produire de brouillage.
2) l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

RF Exposure Statement:
The device is compliance with RF exposure guidelines, users can obtain Canadian information on RF exposure and compliance. The device can be used in portable exposure condition without restriction.

Le présent appareil est conforme Après examen de ce matériel aux conformités ou aux Limites d'intensité de champ RF, les utilisateurs peuvent sur l'exposition aux radiofréquences et compliance d'acquiescer les informations correspondantes. L'appareil peut être utilisé dans des conditions d'exposition portatives sans restriction.

FCC STATEMENT:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.
Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Register your product and get support at www.cleeraudio.com


©2025 Cleer Limited. All rights reserved.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Cleer Limited is under license. Other trademarks and trade names are those of their respective owners.
Dolby, Dolby Audio, and the double-D symbol are trademarks of Dolby Laboratories Licensing Corporation. Manufactured under license from Dolby Laboratories. Confidential unpublished works. Copyright © 1992–2025 Dolby Laboratories. All rights reserved.

THX and the THX Logo are the property of THX Ltd., registered in the U.S. and other countries.

Qualcomm aptX is a product of Qualcomm Technologies International, Ltd. Qualcomm is a trademark of Qualcomm Incorporated, registered in the United States and other countries, used with permission. aptX is a trademark of Qualcomm Technologies International, Ltd., registered in the United States and other countries, used with permission.

Made in China.



Specifications

Driver:	16.2mm neodymium dynamic driver
Audio CODEC support:	aptX™ Lossless, aptX™ Adaptive, AAC, SBC
Frequency response range:	65 Hz - 40 kHz
Connections:	USB-C cable for charging, charging current 5V/2A
Battery capacity:	Earbuds battery: 3.87V 68mAh 0.27Wh Charging case battery: 3.8V 800mAh 3.04Wh
Battery charging (earbuds):	A 10-minute charge will give 2 hours of playtime. Less than 2 hours for a full charge, when charging via USB-C cable.
Playback time:	Up to 7 hours*, Charging case provides an extra 25 hours of use.
Support:	Bluetooth 5.4, A2DP v1.4, AVRCP v1.6.2, HFP v1.9
Weight:	9.5g (per earbud), 75.6g (earbuds and case)

* Data comes from Cleer Lab. The playtime is tested by AAC-encoded audio at 75% volume on Apple mobile device. Specific battery life will vary depending on the volume, connected device and usage habits. Please refer to your mobile device when you use them.


仕様

ドライバー:	16.2mmネオジウムダイナミックドライバー
オーディオコーデック対応:	aptX™ Lossless, aptX™ Adaptive, AAC, SBC
周波数特性レンジ:	65 Hz - 40 kHz
接続:	充電用 USB-C ケーブル。 充電電流 5V/2A
バッテリー容量:	イヤホン: 3.87V 68mAh 0.27Wh 充電ケース: 3.8V 800mAh 3.04Wh
バッテリーを充電する (イヤホン):	10分間の充電で 2 時間再生が可能です。フル充電も 2 時間未満で完了します、USB-C ケーブルで充電する場合。
再生時間:	イヤホン最大 7 時間、充電ケース 25 時間
サポート:	Bluetooth 5.4, A2DP v1.4, AVRCP v1.6.2, HFP v1.9
重量:	9.5g (イヤホン台あたり)、75.6g (イヤホンとケース)

* データはCleer研究所のもので、再生時間はAppleモバイルデバイスを使い、75%の音量で、AACでエンコードされた音声で試験されています。具体的なバッテリー持続時間は音量、接続されたデバイス、使用音源によって異なります。使用する場合は、モバイルデバイスをご参照ください。


Dolby Audio

This feature is disabled by default. You can enable or disable it on demand using the following methods:




Dolby Audio

この機能は、デフォルトでは停止しています。以下の方法で、ニーズに合わせて機能をアクティブ化または無効化することができます。



Touch Control (Music / Call)

* You can customize music touch controls in the Cleer+ App.




イヤホンの操作 (音楽 / 通話)

* ご自身でCleer+ Appのタッチをカスタマイズすることができます。




Touch Control (Volume)

* This feature is unavailable when using one earbud.



イヤホンの操作 (音量)

* 片方のイヤホンだけを使う場合は、この機能は使用できません。



Charging




Use the included USB-C charging cable to charge.

充電する






付属のUSB-C充電ケーブルで充電してください。

LED Behavior



LEDの状態




Restore Factory Settings

Reset with App: Connect Cleer+ App. Tap [Settings] → [Restore factory setting] in the app and complete the process.
Or put the earbuds back to the charging case and long press the MFB button for 10 seconds until a prompt of "Restore Factory Setting" comes out from earbuds.


工場出荷時の設定を復元

Cleer+ Appでリセット: Cleer+ Appに接続後、スワイプしてホームページの設定内の【工場出荷時の設定を復元】をタップし、プロセスを完了してください。
または、両イヤホンを充電ケースに戻し、MFBを10秒間長押しし、イヤホンから「Restore Factory Setting」の音声が出るまで操作してください。

Earbud Peering Mode



イヤホンのペアリングモード



OWN THE MOMENT

Find this user manual on www.cleeraudio.com

Follow us on social media

